

MikroKopter-Setting

Kanäle	MK-Easy		
	Funktion	KopterTool – Einstellungen	Sender – Belegung
Ch1	Gas	Kanäle > GAS > Ch1	Stick links (up/down)
Ch2	Roll	Kanäle > ROLL > Ch2	Stick rechts (left/right)
Ch3	Nick	Kanäle > NICK > Ch3	Stick rechts (up/down)
Ch4	Gier	Kanäle > Gier > Ch4	Stick links (left/right)
Ch5	Auto Start/Land	EasySetup > AutoStart/Land Channel > Ch5	2-fach Schalter
Ch6	Auto-Höhenregelung + GPS	EasySetup > Höhenregelung aktiv + GPS > Ch6	3-fach Schalter
Ch7	CareFree (Headless Mode)	EasySetup > Carefree Steuerung > Ch7	2-fach Schalter
Ch8	Kamera Nick	Kamera > Servo Ansteuerung – Nick > Poti1	Poti
Ch9	Kamera Roll	Kamera > Servo Ansteuerung – Roll > Poti2	Poti
Ch10	Trigger Kamera	Ausgänge > Ausgang1 Timing > Poti3	Taster
Ch11	CamCtrl (off-trigger-rec)	CamCtrl > Mode Kanal > Ch11 + Kamera > Servo 3 > Poti4	3-fach Schalter
Ch12	CamCtrl (zoom)	CamCtrl > Zoom Kanal > Ch12 + Kamera > Servo 4 > Poti5	Poti
Ch13	Video-Umschalter	Kamera > Servo 5 > Poti6	3-fach Schalter
Ch14	Single WP speed	Navi-Ctrl 2 > Single WP Geschw. > Poti7	Poti
Ch15	Single WP control	Navi-Ctrl 2 > Single WP Control Channel > Ch15	3-fach Schalter
Ch16	Next WP channel	Navi-Ctrl 2 > Nächster WP Channel > Ch16	Taster

Channel	MK-Easy		
	Function	KopterTool – Setting	Transmitter – assignment
Ch1	throttle (Gas)	Channels > GAS > Ch1	Stick left (up/down)
Ch2	Roll	Channels > ROLL > Ch2	Stick right (left/right)
Ch3	Nick	Channels > NICK > Ch3	Stick right (up/down)
Ch4	Yaw	Channels > Gier > Ch4	Stick left (left/right)
Ch5	Auto Start/Land	EasySetup > AutoStart/Land Channel > Ch5	2-way Switch
Ch6	AltitudeControl + GPS	EasySetup > Enable Altitude control + GPS > Ch6	3-way Switch
Ch7	CareFree (Headless Mode)	EasySetup > Carefree control > Ch7	2-way Switch
Ch8	Camera Nick	Camera > Servo control – Nick > Poti1	Poti
Ch9	Camera Roll	Camera > Servo control – Roll > Poti2	Poti
Ch10	Trigger camera	Output > Out1 Timing > Poti3	Push-button
Ch11	CamCtrl (off-trigger-rec)	CamCtrl > Mode channel > Ch11 + Camera > Servo 3 > Poti4	3-way Switch
Ch12	CamCtrl (zoom)	CamCtrl > Zoom channel > Ch12 + Camera > Servo 4 > Poti5	Poti
Ch13	Videoswitch	Camera > Servo 5 > Poti6	3-way Switch
Ch14	Single WP speed Yaw / BL-Gimbal	Navi-Ctrl 2 > Single WP speed > Poti7	Poti
Ch15	Single WP control	Navi-Ctrl 2 > Single WP Control Channel > Ch15	3-way Switch
Ch16	Next WP channel	Navi-Ctrl 2 > Next WP Channel > Ch16	Push-button

Extra

KopterTool > Einstellungen

Kanäle > Poti1 > Ch8
Poti2 > Ch9
Poti3 > Ch10
Poti4 > Ch11
Poti5 > Ch12
Poti6 > Ch13
Poti7 > Ch14
Poti8 > Ch15

Motor-Sicherheitsschalter > Disabled

Motor-Start => Gas unten + Gier rechts PLUS Nick unten + Roll links

Motor-Stop => Gas unten + Gier links PLUS Nick unten + Roll rechts



Extra

KopterTool > Settings

Channels > Poti1 > Ch8
Poti2 > Ch9
Poti3 > Ch10
Poti4 > Ch11
Poti5 > Ch12
Poti6 > Ch13
Poti7 > Ch14
Poti8 > Ch15

Motor safety switch > Disabled

Motor-Start => throttle down + yaw right PLUS Nick down + Roll left

Motor-Stop => throttle down + yaw left PLUS Nick down + Roll right

