

MikroKopter - channel assignment

Channel (Kanal)	Assignment in the KopterTool (Belegung im KopterTool)	Functions (Funktionen)
1	Throttle (Gas)	Stick throttle (Steuerung Gas)
2	Roll	Stick roll (Steuerung Roll)
3	Nick	Stick nick (Steuerung Nick)
4	Yaw (Gier)	Stick yaw (Steuerung Gier)
5	-	Function Auto Start/Land
6	-	Function AltitudeControl + GPS (PositionHold/ComingHome) (HöheHalten + GPS)
7	-	Function CareFree (Headless Mode)
8	Poti1	Camera Nick (Servo out 1)
9	Poti2	Camera Roll (Servo out 2)
10	Poti3	trigger camera (Kamera auslösen)
11	Poti4	Servo out 3 => for CamCtrl (out – trigger – REC)
12	Poti5	Servo out 4 => for CamCtrl (zoom in – stop – zoom out)
13	Poti6	Videoswitch (Servo out 5)
14	Poti7	Single WP speed
15	Poti8	Single WP Control Channel
16	-	Next WP Channel